



Basic Line & Matte Line - Medical Reagent Technical Bulletin

Pentadecor 3D laminates are designed to be membrane pressed or vacuum formed to contoured shapes and surface profiles. The 3D forming process eliminates the need for edge banding and visible seams in a wide variety of health care furniture applications. Pentadecor 3DL allows you to design and manufacture healthcare furniture components that are easy to clean, disinfect and maintain.

Pentadecor 3D laminates are naturally hydrophobic and are constructed to withstand the effects of the aggressive cleaners and disinfectants used by healthcare professionals across North America.

Pentadecor Basic Line (BL) and Pentadecor Matte Line (ML) finishes were tested for compatibility with the list of products below using test method NEMA LD3 section 3.4. The Pentadecor BL and ML surface finishes showed no color change or surface damage when tested using this standard.

Cleaners & Disinfectants

- Bleach 5:1
- Citrace® germicide
- Clorox® germicide wipes
- Dispatch® spray with bleach
- Lysol® spray disinfectant
- Precise™ hospital cleaner
- Virex® II 256 Cleaner (diluted per MFG instructions)
- Virex® II 256 cleaner (full strength)
- Bleach-Rite® disinfecting spray
- Fade-A-Dyne® stain remover
- Asepticare TB-II
- Cavicide® surface disinfectant
- SaniZide Plus® germicidal solution
- Rescue Sporicidal Gel
- Accel Cleaner Concentrate
- Accel TB Wipes
- Accel Intervention Wipes
- Accel Prevention Wipes
- Super Sani-Cloth germicidal wipes
- Sani-Cloth HB germicidal wipes
- Sani-Cloth Plus germicidal wipes
- Sani-Cloth AF3 wipes
- Sani-Cloth Bleach wipes
- Prevantics Swab/Swabstick

Usage instructions and surface contact times are unique for each cleaner & disinfectant. It is important to follow the products specific instructions for effectiveness.

SSI North America is the exclusive sales and marketing company for Klockner Pentaplast's Pentadecor 3D laminates in North America. For more information on the North American Pentadecor 3D Laminate program please visit our website; www.ssinorthamerica.com or contact us directly info@ssinorthamerica.com.